

30690 Triumph Tiger 1200 + 900 Handguard Extensions Fitting Instructions

Kit Includes:

2X	C30690	Mouldings (pair)
2X	CFK30690	Brackets (pair)
4X	CBOL0162	M5 X 16mm Bolt
8X	CWAS0105	M5 SS Washer
4X	CNUT0150	M5 Nyloc Nut
2X	CFOA0002	Foam Strip 20mm X 1.5mm (cut to 50mm in length)

- Remove the OEM handguards from the bike by removing the single bolt and washer on the bar end and the single bolt on the inside of the OEM handguard (holding the mirror mounting point).
- Attach the handguard extensions to the brackets using the M5 fittings supplied (shown in **Fig 1**).
- Using a pair of scissors, cut down the centre of the two foam strips lengthways. Remove the backing and attach the foam strips (shown in **Fig 2**).
- **Fig 3** shows how the finished assembly fits together. Refit the OEM handguards as normal with the Pyramid handguards incorporated. Ensure fixings are checked periodically.

